



Design Beyond the Surface

www.atilaminates.com

LUXCORE TUB & SHOWER WALLS






LUXCORE TUB & SHOWER SURROUNDS will are durable FRP panels that pass sanitary codes and are easy to clean. Therefore, it is suitable for wet environments such as commercial baths.

Embrace the bathroom as not just a room of necessity, but one of aesthetical comfort and luxury. LuxCore Tub & Shower Surrounds allow you to refresh your space easily without extensive demolition or cost.

This program has an extensive stock image line that includes granite, tile patterns, fun graphics suitable for kids bathrooms and many other options.

Work with our ATI graphics department to create a completely custom look for your space.

FEATURES

-  **EASY INSTALLATION AND FABRICATION**
-  **HIGH CHEMICAL, SCRATCH AND IMPACT RESISTANCE**
-  **IMPERVIOUS TO WATER**
-  **MADE IN THE USA IN AN ISO CERTIFIED FACILITY**
-  **CHOOSE FROM OUR LIBRARY OF FINISHES, OR SUBMIT YOUR OWN FOR A COMPLETELY CUSTOM LOOK**

KIT INCLUDES

- 2 TUB SIDE PANELS, 30" X 60"**
- 1 TUB BACK PANEL, 60" X 60"**
- 2 ALUMINUM 5' INSIDE CORNER TRIM STRIPS**





INSTALLATION INSTRUCTIONS

LUXCORE SHOWER AND TUB

IT IS RECOMMENDED that you use the services of a skilled professional for installation of LuxCore Shower and Tub panels. However, installation is possible with basic carpentry skills and attention to the details of installation instruction, available as both printed manual and video.

Be sure to acclimatize panels a minimum of 24-48 hours before installation. Special attention should be paid to the drywall substrate and adhesive preparation.

Minor adjustments to cut panels can be made by sanding.

While the standard kit includes two side panels (30" x 60") and a tub back panel (60" x 60"), custom sizes may be available upon request. Trim kits are available as an optional accessory.

INSTALLATION OVERVIEW



SKILL LEVEL:
INTERMEDIATE



TIME NEEDED:
2-3 HOURS



TOOLS REQUIRED:
**CIRCULAR SAW WITH A FINE TOOTH BLADE/
HOLE SAW / J-ROLLER / NOTCH TROWEL**



 VIEW THE INSTALLATION VIDEO:
WWW.ATILAMINATES.COM/RESOURCES/VIDEO/LUXCORE-TUB/