

MirroFlex Tub and Shower Walls Kit Installation Instructions

MirroFlex™ Tub and Shower Walls must be acclimatized for 24 hours before installation!

PLEASE READ ALL INSTRUCTIONS PRIOR TO INSTALLATION:

The guidelines provided herein have been established in good faith to help prevent installation problems. Failure to comply with the following instructions, as well as, the adhesive manufacturers' instructions, may result in significant installation problems.

INSPECTION:



Figure 1

Please inspect MirroFlex Tub and Shower Walls for any imperfections prior to installing; once installed, panels may be very difficult to remove.

Upon opening your package, unroll the panels and lay them flat in the environment in which they will be installed for at least 24 hours prior to installation (Fig. 1).

TOOLS & MATERIALS REQUIRED:



Figure 2

- Razor knife, Scissors
- Tape measure
- J-roller
- Hole saw
- Trowel
- Level
- MirroFlex™ Tub and Shower Walls
- Adhesive – see adhesive chart
- Silicone Sealant
- Soap, Water, & Damp Cloth for Panel Clean-Up
- Mineral Spirits to Remove Excess Adhesive or silicone Sealant
- Painter's tape

CUTTING/FABRICATING:

MirroFlex Tub and Shower Walls can easily be cut to size with a razor knife or scissors. Note: when fabricating MirroFlex, always cut from the decorated side.