



Installation Instructions for MirroFlex™ Door Skins

1. Remove necessary door hardware from door; handle, knocker, and nameplate. (Optional: remove door from hinges and lay on floor stands.)
2. Remove all loose material from face of the door. Lightly sand face of door (or existing old door skin) to rough up surface. Sand around the door face edges approximately 2 inches wide until original door face/skin appears. (This will provide good adhesion of the new skin to the door faces.)
3. Orientate the new skin so the grain direction runs vertical and straight with the edge of the door.
4. Using the recommended 3-M Fastbond 30-NF adhesive, follow the instructions on the container to evenly spread the adhesive over the door surface. Lay the door skin overlapping the top by approximately ¼". If everything looks good and grain is straight, remove backing (if applicable) and roll with small vinyl roller to obtain good adhesion and to remove air pockets. Slowly work down until skin is completely on the door.
5. Trim excess material with utility knife. For best results, use a small hand plane or a block with fine grit sandpaper to ease the edge of the new skin. This will aid in door closing and prevent edge peel.
6. Use utility knife to cut open the new holes to re-install door hardware. (No drilling necessary.) Re-install door (if removed).
7. Check to see that door functions properly.