

MirroFlex®

DIY Decorative BackSplash Panel Kit

Kit includes: Five 18" x 24" BackSplash Panels (15 square feet)
One matching 18" Inside Corner Trim
Two matching 18" J-Trims

Easy Installation Steps



1. PREP THE SURFACE

- Ensure walls are clean, dry, smooth, and grease-free
- Wipe panel backs if needed to ensure good adhesion
- Measure the wall and plan panel placement before starting



2. CUT

- Cut panels using a utility knife or scissors
- Score the finished side, then snap
- Measure and cut outlet & switch openings before install



3. APPLY

- Spray adhesive — Spray-Lock FRP Adhesive
- Tube adhesive — Loctite PL Premium 3X
- Double-sided tape



4. SET THE PANELS

- Press panels firmly across the entire surface
- Re-press edges after 1 hour
- Add J-Trim for finished edges where needed



5. CARE & FINISH

- Clean with mild soap and water only
- Avoid abrasive cleaners



COMPLETE!

Step back. Admire your work.
High-five encouraged!

ATI
DECORATIVE
LAMINATES



MirroFlex®
DIY Decorative
BackSplash
Panel Kit

Install Today. Enjoy Tonight

ATI Decorative Laminates | 800-849-1320 | www.ATILaminates.com

Scan for
Installation
video

