



MirroFlex Cleaning Instructions

There are a variety of different products that make up our MirroFlex Structure product group and in our cleaning instructions we take into consideration the most delicate item in the line.

Always test in a small, inconspicuous area before using any cleaning products.

Use lukewarm, soapy water to remove light dirt. This will not harm many of the finishes and it is the only cleaning method we have tested. You may also dust the part with a soft, damp cloth or chamois and wipe the surface gently. After washing and rinsing, be sure to dry the surface by blotting with a damp cloth or chamois to prevent streaking and water spots.

However, products in your impact wall line are made from 2 different materials - all save Argent Silver and Argent Bronze can use the cleaning instructions detailed below.

Normal cleaning methods may not remove ground in dirt or grease. To remove dirt or grease from texture valleys, a short stiff bristled brush should be used to loosen the material followed by a water rinse.

The following mild detergents and multi-purpose cleaners are recommended:

| | | |
|----------------|--------------|-------------------------|
| *Joy Detergent | *Spic & Span | *Johnson's Pledge |
| *Fantastik | *Mr. Clean | *Janitor in a Drum |
| *Formula 409 | *Cascade | *All Detergent (Powder) |

Ink can be removed from all surfaces with Isopropyl Alcohol.

Permanent Marker can be removed from all but, the Argent Silver and Argent Bronze with Goof-Off Graffiti remover.

Goof-Off Graffiti Remover - www.goof-off.com - 800.345.4530